

BCDS-BFL Boxed Cone Dispenser Stand Instructions

The **DISPENSE-RITE BCDS-BFL** Boxed Cone Dispenser Stand is designed to accommodate a variety of different boxed cone sizes. Please consult the chart shown on the reverse side to determine the proper adapter and baffle plate required for your particular cone type.

INSTALLING PROPER ADAPTER AND BAFFLE PLATE INTO DISPENSER

1. Determine the proper adapter and baffle plate required for your application by referring to the chart shown on the reverse side of this sheet.
2. If the #108 baffle plate is required no further modifications are necessary prior to use. Continue on to instructions below regarding loading your boxed cones into the dispenser.
3. If the #102 baffle plate is required remove the #108 and replace with the #102. Insert the #102 adapter (small adapter) into the two front holes of the unit's head, and push down firmly so that the back tabs sit inside the embossings on the rear of the dispenser head.
4. If the #104 baffle plate is required remove the #108 and replace with the #104. Insert the #104 adapter (large adapter) [if required] into the two front holes of the unit's head, and push down firmly so that the back tabs sit inside the embossings on the rear of the dispenser head.

LOADING THE CONE BOX IN THE DISPENSING STAND

1. Lay your cone box on its side and open the bottom flaps. Remove the carton flaps (tear or cut off). Open the plastic bag liner and stretch the bag up and over the carton sides so that the cones are visible. Remove the chipboard stand and/or pad.
2. Lay the dispenser stand on its side, slide the open end of the cone carton into the dispensing unit.
3. Holding the cone carton securely, stand the entire unit upright. Cones should partially fall through the four holes in the baffle plate.



DISPENSE-RITE®

BCDS-BFL Boxed Cone Dispenser Stand Reference Chart

Cone Manufacturer	Adapter	Baffle
Joy Cone Number		
#1	#102	#102
#10	#102	#102
#22	#104	#104
#30	NONE	#108
#40	NONE	#108
Keebler Cone Number		
#1	#102	#102
#10	#102	#102
#15	#104	#104
#25	#102	#102
#34	NONE	#108
#40	NONE	#108
Novelty Cone Number		
#1	#102	#102
#8	#104	#104
#10	#102	#102
#25	#102	#102
#35	NONE	#104
#55	NONE	#108

DISPENSE-RITE®