

DISPENSE-RITE® GFCD SERIES

ICE CREAM CONE DISPENSER INSTALLATION INSTRUCTIONS

STEP ONE - MOUNTING THE DISPENSER

Gravity fed dispensers may be mounted in any position from vertical to 55 degrees from vertical.

- Position wall bracket in the desired location allowing sufficient clearance to dispense cones.
- Mark location of screw holes on mounting surface.
- Predrill holes for the #10 x 3/4" mounting screws provided.
- Screw wall bracket to mounting surface.

NOTE: Screw anchors may be necessary when mounting on drywall or other thin substrate.

- Position dispenser tube bracket over wall bracket. Slide dispenser into wall bracket until snug.

STEP TWO - LOADING THE DISPENSER

To load flat bottom cones it is not necessary to remove the dispenser from the mounting location:

- Remove top lid.
- Unwrap cones and drop into dispenser tube. Gently feed the first cone through dispenser opening.
- Replace top lid.

To load waffle cones or other heavy, fragile cone types:

- Remove dispenser from mounting location and lay on a clean flat surface.
- Remove top lid. Carefully slide stack of cones into dispenser tube.
- Replace lid and slowly raise the tube. Feed bottom cone through dispenser opening.
- Remount the dispenser.

DISPENSER CLEANING INSTRUCTIONS

All ice cream cones chip and flake slightly. This dispenser has been designed to minimize cone damage and provide a simple means of dispensing a single cone. The dispenser can be completely disassembled without tools making regular cleaning a simple process. Routine cleaning will prolong the life of the dispenser and it will ensure sanitary ice cream cone dispensing.

- Remove dispenser from mounting location.
- Remove top lid. Remove clamp ring and gasket from the bottom of the unit.
- Clean lid, clamp and gasket in hot, soapy water. NOTE: These parts are not dishwasher safe.
- Rinse inside of tube and wipe with a nontoxic cleaner/sanitizer.
- Exterior of tube may be cleaned with any glass cleaner and a soft cloth.
- Reassemble dispenser in reverse of above.

NOTE: THE PLASTIC DISPENSING TUBE SHOULD BE CLEANED WITH SOAPY WATER AND A SOFT CLOTH ONLY. DO NOT USE PAPER TOWELS AS THEY WILL SCRATCH THE TUBE.

GFCD-1: Ice Cream Cone Diameters 1-1/2" - 2-1/4"

GFCD-2: Ice Cream Cone Diameters 2-3/16" - 3-5/16"

DISPENSE-RITE®

Diversified Metal Products, Inc.

2205 Carlson Drive • Northbrook, IL 60062 • (847) 753-9595 • fax (847) 753-9648
www.dispense-rite.com • sales@dispense-rite.com